

PILATUS AIRCRAFT LTD, STANS, SWITZERLAND

SERVICE BULLETIN

PC-12

Service Bulletin No: 27-022

-

Modification No:

Ref No:334ATA Chapter:27

FLIGHT CONTROLS - AILERON CONTROL SYSTEM REPLACEMENT OF THE UNIVERSAL JOINTS IN THE FLIGHT CONTROLS

1. Planning Information

A. Effectivity

PC-12/47E aircraft MSN 1447 thru 1450, 1461, 1462, 1466 thru 1514, 1516 thru 1520 and 1523.

PC-12 Series aircraft where the universal joints (P/N 944.61.73.012 or 527.10.12.195), purchased from March 2014 to, and including, February 2015 were installed as replacement parts.

PC-12 Series aircraft modified with the inspection kit (P/N 500.50.12.314) for the aileron control system, purchased from March 2014 to, and including, February 2015.

Universal joints (P/N 944.61.73.012 or 527.10.12.195) held as spares purchased from March 2014 to, and including, February 2015.

Inspection kits (P/N 500.50.12.314) held as spares purchased from March 2014 to, and including, February 2015.

NOTE: The inspection kit (P/N 500.50.12.314) is used for:

- SB 04-009 (Airworthiness Limitations Life Extension to 25,000 flying hours or 30,000 landings)
- SSID Task 27-10/394 (Aileron Control System Examine). This task is performed initially at 32,500 flying hours or 42,000 landings, whichever comes first, and every 12,500 flying hours or 15,000 landings or 6 years whichever comes first.

B. Concurrent Requirements

None.

C. Reason

A universal joint installed between the control tube assembly and the control column malfunctioned.

D. Solution

Replace the universal joints, as defined in 1. A., with new parts ordered from Pilatus.





E. Description

This Service Bulletin gives the data and instructions necessary to replace the universal joints (P/N 527.10.12.195):

- Part A is for on-aircraft
- Part B is for parts held as spare.

F. Compliance

Mandatory.

For aircraft with less than 200 flights since new or less than 200 flights since the installation of a spare part as defined in 1. A.:

- No more than 10 flights or
- 3 months from the issue date of this Service Bulletin.

For aircraft with more than 200 flights since new or more than 200 flights since the installation of a spare part as defined in 1. A.:

• No later than 1 year after the issue date of this Service Bulletin. This Service Bulletin can be performed at annual inspection.

G. Approval

The technical content of this document is approved under the authority of DOA No. EASA. 21J. 357.

PILATUS advises operators/owners to check with their designated Airworthiness Authority for any changes, local regulations or sanctions that may affect the embodiment of this Service Bulletin.

H. Copyright

© Pilatus Aircraft Ltd. This document contains proprietary information that is protected by copyright. All rights are reserved. No part of this document may be copied, reproduced or translated to other languages without the prior written consent of Pilatus Aircraft Ltd.

I. Manpower

Task	Man-hours	Man-hours At Annual Inspection
Preparation	1.0	0.0
Modification	1.0	1.0
Close-Up	1.0	0.0
TOTAL MAN-HOURS	3.0	1.0

J. Weight and Balance

No change.





K. Electrical load Data

No change.

L. Software

No change.

M. References

Aircraft Maintenance Manual (AMM)

12-B-07-10-00-00A-901A-A 12-B-20-20-01-00A-040A-A 12-B-20-31-00-00A-070A-A 12-B-24-00-00-00A-901A-A 12-B-25-10-01-00A-920A-A 12-B-27-10-00-00A-903A-A 12-B-27-30-00-00A-903A-A

N. Publications Affected

No change.

O. Interchangeability of Parts

Not interchangeable.



PC-12

2. Material Information

A. Material - Price and Availability

If you require more information about this modification, please contact us as follows:

PILATUS AIRCRAFT LTD	General Aviation:
CUSTOMER SUPPORT MANAGER	Tel: + 41 41 619 3333
CH-6371 STANS	Fax: + 41 41 619 7311
SWITZERLAND	eMail: SupportPC12@pilatus-aircraft.com
PILATUS BUSINESS AIRCRAFT LTD PRODUCT SUPPORT DEPARTMENT 11755 AIRPORT WAY BROOMFIELD, CO 80021 UNITED STATES OF AMERICA	Tel: +1 303 465 9099 Fax: +1 303 465 6040 eMail: supportPC12@PilBal.com
PILATUS AUSTRALIA PTY LTD	Tel: +61 8 8238 1600
17 JAMES SCHOFIELD DRIVE	Fax: +61 8 8234 4499
ADELAIDE AIRPORT SA 5950	Free Call: +61 1800 PILATUS (745 2887)
AUSTRALIA	eMail: supportpc12@pilatus.com.au

Operators are requested to advise Pilatus Aircraft Ltd, of the Manufacturer's Serial Number (MSN) and the flying hours of aircraft which are affected by this Service Bulletin.

B. Warranty

Credit will be issued for parts and labour for all affected aircraft on approval of a warranty claim, provided the work is accomplished by an authorised Service Center within 12 months of the issue date of this Service Bulletin.

C. Material Necessary for one Aircraft

NOTE: Part Numbers given in this Service Bulletin are correct at the time of approval. Pilatus Aircraft Ltd. reserves the right to change the part numbers as necessary. Operators are requested to check the IPC for delivered parts which differ from those listed in the Service Bulletin.





PC-	1	2
-----	---	---

(1) Parts to be ordered from Pilatus

New Part No.	Description	Old Part No.	Qty	Disp. Code	Fig	ltem
527.10.12.195	Universal joint (New parts are marked with a placard)	527.10.12.195	2	R	1	1,16
932.19.60.814	BOLT, HEX	932.19.60.814	2	D	1	6, 12
938.77.11.115	WASHER, FLAT	938.77.11.115	2	D	1	10, 14
938.07.68.505	NUT, HEX	938.07.68.505	2	D	1	11, 15
932.35.14.016	BOLT, HEX	932.35.14.016	1	D	1	20
932.35.14.012	BOLT, HEX	932.35.14.012	1	D	1	2
938.77.11.112	WASHER, FLAT	938.77.11.112	2	D	1	3, 17
938.07.68.304	NUT, HEX	938.07.68.304	2	D	1	4, 18

Disposition Codes: D - Discard / N - New / R - Return to Pilatus

D. Operator Supplied Materials (Ref. AMM 12-B-20-31-00-00A-070A-A)

Material No.	Description	Qty	Remarks
P04-039	Corrosion preventive	AR	

E. Tooling - Cost and Availability

None.



3. Part A: Accomplishment Instructions - On Aircraft

A. Preparation

- (1) Raise the aircraft on jacks, refer to AMM 12-B-07-10-00-00A-901A-A.
- (2) De-energize the aircraft electrical system, refer to AMM 12-B-24-00-00-00A-901A-A.
- (3) Open and install a safety clip (Circuit breaker hold open) (P/N 110.88.07.065) on the circuit breaker:

A/P SERVO (AVIONICS BUS).

- (4) Put a warning sign in the cockpit: DO NOT MOVE FLYING CONTROLS.
- (5) Remove the crew seats, refer to AMM 12-B-25-10-01-00A-920A-A.

B. Removal - Pilot Side

Refer to Figure 1.

CAUTION: BE CAREFUL NOT TO DAMAGE THE ADJACENT WIRING LOOM.

- (1) Remove the nut (22) and the bolt (23).
- (2) Remove and discard the nut (15), washer (14) and the bolt (12).
- (3) Remove and discard the nut (18), washer (17) and the bolt (20).
- (4) Move back the control wheel and remove the universal joint (16) (P/N 527.10.12.195) from the control tube assembly (13) and the control column (21).
- (5) Remove the stop block (19) from the universal joint.

C. Installation - Pilot Side

Refer to Figure 1.

- (1) Apply corrosion preventive (Material No. P04-039) to the internal surface of the stop block (19).
- (2) Apply corrosion preventive (Material No. P04-039) to the mating surfaces of the control tube assembly (13) the control column (21) and the new universal joint (16) (P/N 527.10.12.195).
- (3) Put the stop block (19) on the universal joint (16) (P/N 527.10.12.195) and align the holes.
- (4) Install the new universal joint (16) (P/N 527.10.12.195) to the control column (21).
- (5) Install the control tube assembly (13) to the universal joint (16) (P/N 527.10.12.195) and align the holes.
- (6) Install the new bolt (20) (P/N 932.35.14.016), washer (17) (P/N 938.77.11.112) and the nut (18) (P/N 938.07.68.304).





- Install the new bolt (12) (P/N 932.19.60.814), washer (14) (P/N 938.77.11.115) and the nut (15) (P/N 938.07.68.505).
- (8) Install the bolt (23) and the nut (22).
- (9) Torque the nuts to the standard torque values, refer to AMM 12-B-20-20-01-00A-040A-A.

D. Removal - Co-pilot Side

Refer to Figure 1.

CAUTION: BE CAREFUL NOT TO DAMAGE THE ADJACENT WIRING LOOM.

- (1) Remove the nut (8) and the bolt (9).
- (2) Remove and discard the nut (11), washer (10) and the bolt (6).
- (3) Remove and discard the nut (4), washer (3) and the bolt (2).
- (4) Move back the control wheel and remove the universal joint (1) (P/N 527.10.12.195) from the control tube assembly (7) and the control column (5).

E. Installation - Co-pilot Side

Refer to Figure 1.

- Apply corrosion preventive (Material No. P04-039) to the mating surfaces of the control tube assembly (7) the control column assembly (5) and the new universal joint (1) (P/N 527.10.12.195).
- (2) Install the new universal joint (1) (P/N 527.10.12.195) to the control column (5).
- (3) Install the control tube assembly (7) to the universal joint (1) (P/N 527.10.12.195) and align the holes.
- (4) Install the new bolt (2) (P/N 932.35.14.012), washer (3) (P/N 938.77.11.112) and the nut
 (4) (P/N 938.07.68.304).
- Install the new bolt (6) (P/N 932.19.60.814), washer (10) (P/N 938.77.11.115) and the nut (11) (P/N 938.07.68.505).
- (6) Install the bolt (9) and the nut (8).
- (7) Torque the nuts to the standard torque values, refer to AMM 12-B-20-20-01-00A-040A-A.

F. Close Up

- (1) Do an functional test of the aileron control system, refer to AMM 12-B-27-10-00-00A-903A-A.
- (2) Do an functional test of the elevator control system, refer to AMM 12-B-27-30-00-00A-903A-A.
- (3) Make sure that the work area is clean and clear of tools and other items.
- (4) Install the crew seats, refer to AMM 12-B-25-10-01-00A-920A-A.





(5) Remove the safety clip and close the circuit breaker:

A/P SERVO (AVIONICS BUS).

- (6) Remove the warning sign from the cockpit.
- (7) Lower the aircraft to the ground and remove the jacks, refer to AMM 12-B-07-10-00-00A-901A-A.

G. Documentation

- (1) Record in the aircraft logbook that this Service Bulletin has been accomplished.
- (2) Mark the removed universal joints "unserviceable" and return to Pilatus at the applicable address below:

PILATUS AIRCRAFT LTD WARRANTY COORDINATOR ENNETBÜRGENSTRASSE 101 CH-6371 STANS SWITZERLAND

PILATUS BUSINESS AIRCRAFT LTD PARTS SALES AND SERVICES 11755 AIRPORT WAY BROOMFIELD, CO 80021 UNITED STATES OF AMERICA Attn: Mr Stefan Brun Tel: + 41 41 619 3333

Attn: Mr Jerry Frank Tel: +1 303 465 9099





4. Part B: Accomplishment Instructions - Spares

A. Instruction

Parts held as spares must be marked "unserviceable" and return to Pilatus at the applicable address below:

PILATUS AIRCRAFT LTD WARRANTY COORDINATOR ENNETBÜRGENSTRASSE 101 CH-6371 STANS SWITZERLAND Attn: Mr Stefan Brun Tel: + 41 41 619 3333

PILATUS BUSINESS AIRCRAFT LTD PARTS SALES AND SERVICES 11755 AIRPORT WAY BROOMFIELD, CO 80021 UNITED STATES OF AMERICA Attn: Mr Jerry Frank Tel: +1 303 465 9099



SERVICE BULLETIN





